



HONDA SH 350 2021 ATT. FABBRI

3435/A – 3438/LS – 3435/BE att. 3437/E



3435/A



3438/LS



3435/BE



Close-up right side

- 1) Unscrew the rear view mirrors
- 2) Pre assemble bolt M10x80, flat washer, grower, metallic support (right side in the picture and bush 14x55
- 3) Fix without tightening



Left side

- 1) Insert the plastic clamps on support (as picture aside)
- 2) Pre assemble the screen fixing system
- 3) Center the screen and fix all nuts and bolt without over-tighten
- 4) Fix the mirrors, without Honda original colums supports, by provided left thread nuts

LH/RH supports	1+1
Flat washer	2
Grower	2
Bush 14x55	2
Bolt M10x80	2
Nut left thread	2